

Table of Contents

Introduction.....	2
Menu File.....	3
New.....	3
Start a new UWOT project.....	3
Open file.....	3
Reopen.....	3
Save.....	3
Save as.....	3
Export.....	3
Menu Edit.....	4
View.....	5
Project menu.....	6
Edit groups.....	6
Add brand.....	6
Del brand.....	6
Copy hyper.....	6
Input timeseries.....	6
Frequency override series.....	6
Output timeseries.....	6
Process menu.....	7
Help menu.....	8
Components.....	8
GUI.....	8
About.....	8
Network view.....	9
Spatial view.....	10

Introduction

This document describes the UI of UWOT.

Menu File

f

New

f

Start a new UWOT project.

f

Open file

Open an existing UWOT project.

f

Reopen

Open one of the last UWOT project.

Quickly access a recently opened UWOT project.

Save

Save changes of current project.

Save as

Save current project with a different name.

Export

Export svg file: export the Network view to an svg file.

Export files: Export the current project to text files to be read by Matlab version of UWOT.

Menu Edit

Undo: undo last action

Redo: redo last action

Copy all as SVG: copy all to clipboard as svg image

View

Arrange the current view (pan, zoom in/out, full extent view, define what labels to show on view).

Project menu

F

Edit groups

f

Add brand

f

Del brand

f

Copy hyper

f

Input timeseries

f

Frequency override series

f

Output timeseries

f

Process menu

Run the project

Help menu

Provides help on UWOT.

Components

Provides documentation regarding the operation of the UWOT components.

GUI

Describes the UWOT user interface.

About

About UWOT development.

Network view

Spatial view